

# ECM-QM57

Intel® Core™ i7/i5/Celeron 3.5" Micro Module with Intel® QM57 Chipset

## Quick Installation Guide



1<sup>st</sup> Ed – 30 August 2010

### FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

### Copyright Notice

Copyright © 2010 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

### A Message to the Customer

#### ***Avalue Customer Services***

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

#### ***Technical Support***

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more

2 ECM-QM57 Quick Installation Guide

## ECM-QM57 Quick Installation Guide

detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalu.com.tw/>

If you still cannot find the answer, gather all the information or questions that apply to your problem, and with the product close at hand, call your dealer. Our dealers are well trained and ready to give you the support you need to get the most from your Avalue's products. In fact, most problems reported are minor and are able to be easily solved over the phone.

In addition, free technical support is available from Avalue's engineers every business day. We are always ready to give advice on application requirements or specific information on the installation and operation of any of our products. Please do not hesitate to call or e-mail us.

### Headquarters and Branch

#### Avalue Technology Inc.

7F, 228, Lian-cheng Road, Chung Ho City, Taipei, Taiwan

Tel: +886-2-8226-2345

Fax: +886-2-8226-2777

Information: [sales@avalu.com.tw](mailto:sales@avalu.com.tw)

Service: [service@avalu.com.tw](mailto:service@avalu.com.tw)

---

#### Avalue USA

##### Avalue Technology Inc.

200 Tornillo Way, Suite 210, Tinton Falls,  
NJ 07712

Tel: +1-732-578-0200

Fax: +1-732-578-0250

Information: [sales@avalu-usa.com](mailto:sales@avalu-usa.com)

Service: [support@avalu-usa.com](mailto:support@avalu-usa.com)

---

#### Avalue Europe

##### Avalue Europe A/S

Moelledalen 22C, 3140  
Aalsgaarde, Denmark

Tel: +45-7025-0310

Fax: +45-4975-5026

Information: [sales.europe@avalu.com.tw](mailto:sales.europe@avalu.com.tw)

Service: [service.europe@avalu.com.tw](mailto:service.europe@avalu.com.tw)

---

#### BCM Advanced Research

##### BCM Advanced Research an Avalue Company

7 Marconi, Irvine, CA92618

Tel: +1-949-470-1888

Fax: +1-949-470-0971

Information: [BCMSales@bcmcom.com](mailto:BCMSales@bcmcom.com)

Web: [www.bcmcom.com](http://www.bcmcom.com)

---

#### Avalue China

##### Avalue Technology Inc.

Room 805, Building 9, No.99 Tianzhou Rd.,  
Caohejing Development Area,  
Xuhui District, Shanghai

Tel: +86-21-5169-3609

Fax: +86-21-5445-3266

Information: [sales.china@avalu.com.cn](mailto:sales.china@avalu.com.cn)

Service: [service@avalu.com.tw](mailto:service@avalu.com.tw)

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

**Always note** that improper disassembling action could cause damage to the motherboard. We suggest not removing the heatsink without correct instructions in any circumstance. If you really have to do this, please contact us for further support.

## 1.2 Packing List


Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x 3.5" ECM-QM57 Micro Module
- 1 x Quick Installation Guide for ECM-QM57
- 1 x AUX-032 daughter board
- 1 x DVD-ROM contains the followings:
  - User's Manual (this manual in PDF file)
  - Ethernet driver and utilities
  - VGA drivers and utilities
  - Audio drivers and utilities
- 1 x Cable set contains the followings:
  - 1 x Audio cable (12pin, 2.0mm pitch)
  - 1 x USB cable (10P/2.54mm-10P/2.0mm)
  - 1 x Serial ATA cable (7-pin, standard)
  - 1 x Serial ATA cable (15-pin, 2P/2.0mm)

# 2. Hardware Configuration

---


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board’s jumpers and connectors.

### Jumpers

Label	Function	Note
JBAT1	Clear CMOS	3 x 1 header, pitch 2.54 mm
JRI1	Serial port 1 pin 9 signal select	3 x 2 header, pitch 2.0 mm
PWR_MSEL1	Input power select	2 x 1 header, pitch 2.54 mm

## ECM-QM57 Quick Installation Guide



### Connectors

Label	Function	Note
<b>BBAT1</b>	Battery connector	2 x 1 wafer, pitch 1.25 mm
<b>BLED1</b>	CFAST LED connector 1	2 x 1 header, pitch 2.0 mm
<b>BLED2</b>	CFAST LED connector 2	2 x 1 header, pitch 2.0 mm
<b>COM1</b>	Serial port 1 connector	D-sub 9-pin, male
<b>CPU_FAN1</b>	CPU fan connector	3 x 1 wafer, pitch 2.54 mm
<b>FPC_PCIE1</b>	PCIe slot	
<b>HDMI1</b>	HDMI connector	
<b>J422/485</b>	Serial port 1 in RS-422/485 mode	3 x 2 header, pitch 2.0 mm
<b>JAUDIO1</b>	Audio connector	7 x 2 header, pitch 2.0 mm
<b>JBKL1</b>	+12V power connector	2 x 1 wafer, pitch 2.0 mm
<b>JBKL2</b>	LCD inverter connector	5 x 1 wafer, pitch 2.0 mm
<b>JBKL3</b>	LED backlight adjustment connector 1	2 x 1 header, pitch 2.0 mm
<b>JBKL4</b>	LED backlight adjustment connector 2	2 x 1 header, pitch 2.0 mm
<b>JCOM2</b>	Serial port 2 connector	5 x 2 header, pitch 2.0 mm
<b>JDIO1</b>	General purpose I/O connector	10 x 2 header, pitch 2.0 mm
<b>JFP1</b>	Miscellaneous setting connector	5 x 2 header, pitch 2.0 mm
<b>JLPC1</b>	Low pin count interface	7 x 2 header, pitch 2.0 mm
<b>JLVDS1</b>	LVDS connector	
<b>JSPI1</b>	SPI connector	4 x 2 header, pitch 2.0 mm
<b>JUSB45</b>	USB connector 8 & 9	5 x 2 header, pitch 2.0 mm
<b>JUSB67</b>	USB connector 10 & 11	5 x 2 header, pitch 2.0 mm
<b>JVR1</b>	LCD backlight brightness adjustment	3 x 1 header, pitch 2.54 mm
<b>LAN1/ LAN2</b>	RJ-45 Ethernet connector	
<b>LED2</b>	LED connector	
<b>PWR_SB1</b>	5VSB connector in ATX	3 x 1 wafer, pitch 2.54 mm
<b>PWRCON1</b>	Power connector	2 x 2 wafer, pitch 4.2 mm
<b>SATA_PWR1</b>	SATA power connector	2 x 1 wafer, pitch 2.0 mm
<b>SATA_PWR2</b>	SATA power connector	2 x 1 wafer, pitch 2.0 mm
<b>SATA1</b>	Serial ATA connector 1	
<b>SATA2</b>	Serial ATA connector 2	
<b>SYS_FAN1</b>	System fan connector	3 x 1 wafer, pitch 2.54 mm
<b>USB1</b>	USB connector 2	
<b>VGA1</b>	VGA connector	D-sub 15-pin, female





## 2.3 Setting Jumpers & Connectors

### 2.3.1 Clear CMOS (JBAT1)



\* Default


### 2.3.2 Serial port 1 pin 9 signal select (JRI1)




\* Default

# ECM-QM57 Quick Installation Guide

## 2.3.3 AT/ ATX Input power select (PWR\_MSEL1)



AT\*





ATX



\* Default






## 2.3.4 5VSB connector in ATX (PWR\_SB)



Signal	PIN
ATX5VSB	3
GND	2
PSON	1



# ECM-QM57 Quick Installation Guide

## 2.3.4.1 Signal Description –AT/ATX mode & Input power type

Input power type	Power-ON Mode	Description
<p data-bbox="261 573 368 607">AT Type</p>	<p data-bbox="647 311 836 387">AT Mode (PWR_MSEL1)</p> 	<p data-bbox="1010 405 1436 481">Use AT type power input, and set the board in AT mode.</p>
	<p data-bbox="647 602 836 678">ATX Mode (PWR_MSEL1)</p> 	<p data-bbox="1010 696 1436 772">Use AT type power input, and set the board in ATX mode.</p>
<p data-bbox="248 1037 381 1113">ATX Type (PWR_SB)</p> 	<p data-bbox="647 889 836 965">AT Mode (PWR_MSEL1)</p> 	<p data-bbox="1010 983 1436 1059">Use ATX type power input, and set the board in AT mode.</p>
	<p data-bbox="647 1180 836 1256">ATX Mode (PWR_MSEL1)</p> 	<p data-bbox="1031 1252 1415 1377">Use ATX type power input, and set the board in ATX mode.</p>



# ECM-QM57 Quick Installation Guide

## 2.3.5 Battery connector (BBAT1)



Signal	PIN
GND	2
VBAT	1



## 2.3.6 CFAST LED connector (BLED1/ BLED2)



Signal	PIN
GND	2
BLED1/ BLED2	1



# ECM-QM57 Quick Installation Guide

## 2.3.7 CPU fan connector (CPU\_FAN1/ SYS\_FAN1)



Signal	PIN
GND	1
CPU_FAN_PWR/ SYS_FAN_PWR	2
CPUFANIN/ SYSFANIN	3



## 2.3.8 Serial port 1 in RS-422/485 mode (J422/485)



Signal	PIN	PIN	Signal
485RX-	2	1	485TX-
485RX+	4	3	485TX+
GND	6	5	+5V



# ECM-QM57 Quick Installation Guide

## 2.3.9 Audio connector (JAUDIO1)



Signal	PIN	PIN	Signal
GND	12	11	MIC1_JD
LIN1_JD	10	9	FRONT_JD
MIC1_L	8	7	MIC1_R
LIN1_L	6	5	LIN1_R
GND	4	3	GND
FRONT_L	2	1	FRONT_R



## 2.3.10 +12V power connector (JBKL1)




Signal	PIN
+12V	1
GND	2

# ECM-QM57 Quick Installation Guide

## 2.3.11 LCD backlight brightness adjustment (JVR1)





Signal	PIN
+5V	1
BRIGHT	2
GND	3



Variation Resistor  
(Recommended: 4.7KΩ,  
>1/16W)


## 2.3.12 Low pin count connector (JLPC1)



Signal	PIN	PIN	Signal
GND	14	13	+5V
GND	12	11	+5V
GND	10	9	INT_SERIRQ
CLK_LPC	8	7	LPC_AD3
LPC_FRAME#	6	5	LPC_AD2
PLT_RST#	4	3	LPC_AD1
+3.3V	2	1	LPC_AD0

# ECM-QM57 Quick Installation Guide

## 2.3.13 LCD Inverter Connector (JBKL2)



Signal	PIN
+12V	1
GND	2
BLEN	3
L_BKLT_CTRL_R	4
+5V	5



**Note:**

For inverters with adjustable Backlight function, it is possible to control the LCD brightness through the VR signal controlled by **JVR1**. Please see the **JVR1** section for detailed circuitry information.



### 2.3.13.1 Signal Description – LCD Inverter Connector (JBKL2)

Signal	Signal Description
L_BKLT_CTRL_R	Vadj = 0.75V ~ 4.25V (Recommended: 4.7KΩ, >1/16W)
BLEN	LCD backlight ON/OFF control signal





# ECM-QM57 Quick Installation Guide

## 2.3.14 LED backlight adjustment connector (JBKL3/ JBKL4)



Signal	PIN
GPIO7/ DGPU_HPD_INTR#	1
GND	2



## 2.3.15 Serial port 2 connector (JCOM2)



Signal	PIN	PIN	Signal
DCD2	1	2	RxDD2
TxDD2	3	4	DTR2
GND	5	6	DSR2
RTS2	7	8	CTS2
RI2	9	10	NC

# ECM-QM57 Quick Installation Guide



## 2.3.16 General purpose I/O connector (JDIO)



Signal	PIN	PIN	Signal
DIO_GP20	1	2	DIO_GP10
DIO_GP21	3	4	DIO_GP11
DIO_GP22	5	6	DIO_GP12
DIO_GP23	7	8	DIO_GP13
DIO_GP24	9	10	DIO_GP14
DIO_GP25	11	12	DIO_GP15
DIO_GP26	13	14	DIO_GP16
DIO_GP27	15	16	DIO_GP17
SMBCLK_MAIN	17	18	SMBDATA_MAIN
GND	19	20	+5V


# ECM-QM57 Quick Installation Guide

## 2.3.17 Miscellaneous setting connector (JFP)



Signal	PIN
PEBT	1
	2
RST#	3
	4
PWR-LED	5
	6
HDD-LED	7
	8
COPEN#	9
	10



## 2.3.18 SPI connector (JSPI1)



Signal	PIN	PIN	Signal
+3.3V	1	2	GND
SPI_CS#0	3	4	SPI_CLK
SPISO	5	6	SPI_SI
HOLD#_R	7		

# ECM-QM57 Quick Installation Guide



## 2.3.19 LVDS connector (JLVDS1)



Signal	PIN	PIN	Signal
+5V	2	1	+3.3V
+5V	4	3	+3.3V
LVDS_DDC_DATA	6	5	LVDS_DDC_CLK
GND	8	7	GND
LVDSA_DATA0	10	9	LVDSA_DATA1
LVDSA_DATA0#	12	11	LVDSA_DATA1#
GND	14	13	GND
LVDSA_DATA2	16	15	LVDSA_DATA3
LVDSA_DATA2#	18	17	LVDSA_DATA3#
GND	20	19	GND
LVDSB_DATA0	22	21	LVDSB_DATA1
LVDSB_DATA0#	24	23	LVDSB_DATA1#
GND	26	25	GND
LVDSB_DATA2	28	27	LVDSB_DATA3
LVDSB_DATA2#	30	29	LVDSB_DATA3#
GND	32	31	GND
LVDSA_CLK	34	33	LVDSB_CLK
LVDSA_CLK#	36	35	LVDSB_CLK#
GND	38	37	GND
+12V	40	39	+12V


# ECM-QM57 Quick Installation Guide

## 2.3.20 USB connector 8 & 9/ 10 & 11 (JUSB45/ JUSB67)



Signal	PIN	PIN	Signal
+5V	1	2	GND
N8/ N10	3	4	GND
P8/ P10	5	6	P9/ P11
GND	7	8	N9 N11
GND	9	10	+5V


## 2.3.21 Power connector (PWRCON1)



Signal	PIN	PIN	Signal
GND	2	4	VIN
GND	1	3	VIN

## 2.4 Audio / USB Daughter Board User's Guide

### 2.4.1 Jumper and Connector Layout



### 2.4.2 Jumper and Connector List

#### Connectors

Label	Function	Note
<b>CN1, CN2</b>	USB connector	
<b>CN4</b>	Line out connector	Phone Jack
<b>CN5</b>	Line in connector	Phone Jack
<b>CN6</b>	Mic in connector	Phone Jack
<b>JAUDIO</b>	Audio connector	6 x 2 header, pitch 2.0mm
<b>JP1</b>	2.54mm USB connector	5 x 2 header, pitch 2.54mm
<b>JP2</b>	2.54mm USB connector	5 x 2 header, pitch 2.54mm
<b>JP4</b>	2.0mm USB connector	5 x 2 header, pitch 2.0mm
<b>JP5</b>	2.0mm USB connector	5 x 2 header, pitch 2.0mm
<b>JP7</b>	TV / Audio connector	8 x 2 header, pitch 2.54mm

# ECM-QM57 Quick Installation Guide

## 2.4.3 Setting Jumper and Connector

### Audio Connector (JAUDIO)

Signal	PIN	PIN	Signal
OUTR	1	2	OUTL
GND	3	4	GND
INR1	5	6	INL1
MICIN1	7	8	AREF
FRONT-JD1	9	10	LINE1-JD1
MIC1-JD1	11	12	GND

### 2.54mm USB Connector (JP1)

Signal	PIN	PIN	Signal
+5V	1	2	GND
D1-	3	4	GND
D1+	5	6	D2+
GND	7	8	D2-
GND	9	10	+5V



**Note:** Wrong USB cable configuration with your USB devices might cause your USB devices damaged.

### 2.54mm USB Connector (JP2)

Signal	PIN	PIN	Signal
+5V	1	2	GND
D3-	3	4	GND
D3+	5	6	D4+
GND	7	8	D4-
GND	9	10	+5V

### TV / Audio Connector (JP7)

Signal	PIN	PIN	Signal
Mic In	1	2	Mic Bais
GND	3	4	GND
Line out L	5	6	Line out R
SPK L	7	8	SPK R
Line in L	9	10	Line in R
GND	11	12	NC
TVGND	13	14	NC
TVGND	15	16	COMP

### 2.0mm USB Connector (JP4)

Signal	PIN	PIN	Signal
+5V	1	2	GND
D3-	3	4	GND
D3+	5	6	D4+
GND	7	8	D4-
GND	9	10	+5V

### 2.0mm USB Connector (JP5)

Signal	PIN	PIN	Signal
+5V	1	2	GND
D1-	3	4	GND
D1+	5	6	D2+
GND	7	8	D2-
GND	9	10	+5V

**ECM-QM57 Quick Installation Guide**

