

# **ECM-CDV**

**3.5" Intel Cedarview Module**

## **Quick Installation Guide**



**2<sup>nd</sup> Ed – 22 March 2012**

### FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

### Copyright Notice

Copyright © 2011-2012 Avalue Technology Inc., ALL RIGHTS RESERVED.

No part of this document may be reproduced, copied, translated, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the prior written permission of the original manufacturer.

### Disclaimer

Avalue Technology Inc. reserves the right to make changes, without notice, to any product, including circuits and/or software described or contained in this manual in order to improve design and/or performance. Avalue Technology assumes no responsibility or liability for the use of the described product(s), conveys no license or title under any patent, copyright, or masks work rights to these products, and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified. Applications that are described in this manual are for illustration purposes only. Avalue Technology Inc. makes no representation or warranty that such application will be suitable for the specified use without further testing or modification.

# Content

<b>1. Getting Started</b>	<b>4</b>
1.1 Safety Precautions	4
1.2 Packing List	4
<b>2. Hardware Configuration</b>	<b>5</b>
2.1 Product Overview	6
2.2 Jumper and Connector List	7
2.3 Setting Jumpers & Connectors	9
2.3.1 Clear CMOS (CMOS1)	9
2.3.2 Touch Mode selector (JP1)	9
2.3.3 Miscellaneous settings connector (FPT1)	10
2.3.4 Serial port 1/ 2 signal select (JRI1/ JRI2)	11
2.3.5 LCD PWM Mode Selector (BPW M1)	11
2.3.6 Battery connector (BT1)	12
2.3.7 Power connector (PWR1)	12
2.3.8 Audio connector (AUD1)	13
2.3.9 Touch connector (TOUCH1)	13
2.3.10 LCD inverter connector (BKL1)	14
2.3.10.1 Signal Description – LCD Inverter Connector (BKL1)	14
2.3.11 LCD backlight brightness adjustment (VR1)	15
2.3.12 LVDS connector (LVDS1)	15
2.3.13 USB connector 0&1 / 2&3 / 4&5 (USB2/ 3/ 4)	16
2.3.14 LPC connector (LPC1)	16
2.3.15 SPI connector (SPI1)	17
2.3.16 Serial port 2 connector (COM2)	17
2.3.17 Keyboard & Mouse Connector (KB1)	18
2.3.18 Serial port 2 in RS-422-485 mode (RS1)	18
2.3.19 General purpose I/O connector (DIO1)	19
2.3.20 SATA power connector (SPWR1)	19
2.3.21 CPU fan connector (FAN1)	20
2.3.22 System fan connector (FAN2)	20

# 1. Getting Started

## 1.1 Safety Precautions

### Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

### Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

**Always note** that improper disassembling action could cause damage to the motherboard. We suggest not removing the heatsink without correct instructions in any circumstance. If you really have to do this, please contact us for further support.

## 1.2 Packing List


Before you begin installing your single board, please make sure that the following materials have been shipped:

- 1 x 3.5" ECM-CDV Micro Module
- 1 x Quick Installation Guide for ECM-CDV
- 1 x AUX-032 daughter board
- 1 x DVD-ROM contains the followings:
  - User's Manual (this manual in PDF file)
  - Ethernet driver and utilities
  - VGA drivers and utilities
  - Audio drivers and utilities
- 1 x Cable set contains the followings:
  - 1 x Audio cable (12pin, 2.0mm pitch)
  - 1 x USB cable
  - 1 x Serial ATA cable (7-pin, standard).
  - 1 x Wire SATA power (15-pin, 2P/2.0mm)
  - 1 x Flat Cable 9P(M)-Dupont 10P/2.0mm)
- 3M Foam (VHB-4622 10mm\*20mm\*1.1mm)

# 2. Hardware Configuration

---


## 2.1 Product Overview



## 2.2 Jumper and Connector List

You can configure your board to match the needs of your application by setting jumpers. A jumper is the simplest kind of electric switch.

It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper you connect the pins with the clip. To “open” a jumper you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2, and 3. In this case, you would connect either two pins.



The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers.

Connectors on the board are linked to external devices such as hard disk drives, a keyboard, or floppy drives. In addition, the board has a number of jumpers that allow you to configure your system to suit your application.

If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes.

The following tables list the function of each of the board’s jumpers and connectors.

### Jumpers

Label	Function	Note
<b>CMOS1</b>	Clear CMOS	3 x 1 header, pitch 2.54 mm
<b>FPT1</b>	Miscellaneous settings connector	6 x 2 header, pitch 2.0 mm
<b>JP1</b>	Touch Mode selector	3 x 1 header, pitch 2.0 mm
<b>JRI1/ JRI2</b>	Serial port 1/2 signal selector	3 x 2 header, pitch 2.0 mm
<b>BPW M1</b>	LCD PWM Mode Selector	2 x 1 header, pitch 2.0 mm

## ECM-CDV Quick Installation Guide


### Connectors

Label	Function	Note
<b>AUD1</b>	Audio connector	6 x 2 header, pitch 2.0 mm
<b>BKL1</b>	LCD inverter connector	5 x 1 wafer, pitch 2.0mm
<b>BT1</b>	Battery connector	2 x 1 wafer, pitch 1.25 mm
<b>CF1</b>	CF card slot	CF type II
<b>COM1</b>	Serial port 1 connector	D-sub 9-pin, male
<b>COM2</b>	Serial port 2 connector	5 x 2 header, pitch 2.0 mm
<b>CRT1</b>	CRT connector	D-sub 15-pin, female
<b>DIO1</b>	General purpose I/O connector	10 x 2 header, pitch 2.0 mm
<b>D12</b>	Power & HDD LED indicator	
<b>FAN1</b>	CPU fan connector	4 x 1 wafer, pitch 2.54 mm
<b>FAN2</b>	System fan connector	3 x 1 wafer, pitch 2.54 mm
<b>LVDS1</b>	LVDS connector	2 x 20 header, pitch 1.25mm
<b>HDMI1</b>	HDMI connector	
<b>KB1</b>	Keyboard & Mouse Connector	4 x 2 header, pitch 2.0 mm
<b>LAN1/2</b>	RJ-45 Ethernet connector 1/2	
<b>LPC1</b>	LPC connector	7 x 2 header, pitch 2.0 mm
<b>MPCIE1</b>	Mini PCI Express Connector	
<b>PWR1</b>	Power connector	2 x 2 wafer, pitch 4.2 mm
<b>RS1</b>	Serial port 2 in RS-422-485 mode	3 x 2 header, pitch 2.0 mm
<b>SODIMM1</b>	DDR3 SODIMM connector	204-pin
<b>SPI1</b>	SPI connector	4 x 2 header, pitch 2.0 mm
<b>SPWR1</b>	SATA power connector 1	2 x 1 wafer, pitch 2.0 mm
<b>SATA1</b>	Serial ATA connector 1	
<b>TOUCH1</b>	Touch connector	9 x 1 wafer, pitch 2.0 mm
<b>USB1</b>	USB connector 1	USB connector
<b>USB2/ 3/ 4</b>	USB connector 0&1 / 2&3 / 4&5	5 x 2 header, pitch 2.0 mm
<b>VR1</b>	LCD backlight brightness adjustment	3 x 1 header, pitch 2.54mm




## 2.3 Setting Jumpers & Connectors


### 2.3.1 Clear CMOS (CMOS1)



Protect\*




Clear CMOS




\* Default


### 2.3.2 Touch Mode select (JP1)



5-Wire\*




4/8-Wire



\* Default


# ECM-CDV Quick Installation Guide

## 2.3.3 Miscellaneous settings connector (FPT1)




\* Default


### Power Button




### ATX Mode\*




### AT Mode




### System Reset



### HDD LED Mode





### Power LED Mode



Signal	PIN	PIN	Signal
HDD_LED-	1	2	PWR_LED+
HDD_LED+	3	4	GND
GND	5	6	PWRSB_LED+
SYSRST	7	8	PWRSB_LED-
DS5_PANSW IN#	9	10	GND
ATX_EN#	11	12	ATX_EN#

# ECM-CDV Quick Installation Guide



## 2.3.4 Serial port 1/ 2 signal select (JRI1/ JRI2)



Signal	PIN	PIN	Signal
JNRIA/B#	1	2	NRIA/B#
+5V	3	4	NRIA/B#
+12V	5	6	NRIA/B#

\* Default

## 2.3.5 LCD PWM Mode Selector (BPW M1)





Signal	PIN
BRIGHT	1
LVDS_BKLTCTL	2

\* Default



# ECM-CDV Quick Installation Guide

## 2.3.6 Battery connector (BT1)



Signal	PIN
BAT	1
GND	2



## 2.3.7 Power connector (PWR1)



Signal	PIN	PIN	Signal
GND	1	2	GND
+12~26V	3	4	+12~26V



## ECM-CDV Quick Installation Guide

### 2.3.8 Audio connector (AUD1)



Signal	PIN	PIN	Signal
GND	12	11	MIC1-JD
LINE1-JD	10	9	FRONT-JD
MIC-LIN	8	7	MIC-RIN
LINE1_LIN	6	5	LINE1_RIN
GND	4	3	GND
LINEOUT_L	2	1	LINEOUT_R



### 2.3.9 Touch connector (TOUCH1)



Signal	PIN	4-Wire	5-Wire	8-Wire
X+	1	NA	NA	Right Sense
X-	2	NA	NA	Left Sense
Y+	3	NA	NA	Bottom Sense
SENSE	4	NA	Sense	Top Sense
X+	5	Right	LR	Right Excite
X-	6	Left	LL	Left Excite
Y+	7	Bottom	UR	Bottom Excite
Y-	8	Top	UL	Top Excite
TOUCH_GND	9	GND	GND	GND

# ECM-CDV Quick Installation Guide

## 2.3.10 LCD inverter connector (BKL1)



Signal	PIN
+12V	1
GND	2
LVDS_BLKTEN	3
BRIGHT	4
+5V	5

**Note:**



For inverters with adjustable Backlight function, it is possible to control the LCD brightness through the VR signal controlled by **VR1**.

### 2.3.10.1 Signal Description – LCD Inverter Connector (BKL1)


Signal	Signal Description
BRIGHT	$V_{adj} = 0.75V \sim 4.25V$ (Recommended: $4.7K\Omega$ , $>1/16W$ )
LVDS_BLKTEN	LCD backlight ON/OFF control signal

# ECM-CDV Quick Installation Guide

## 2.3.11 LCD backlight brightness adjustment (VR1)




Signal	PIN
GND	3
BRIGHT	2
+5V	1



Variation Resistor

(Recommended: 4.7KΩ, >1/16W)



## 2.3.12 LVDS connector (LVDS1)



Signal	PIN	PIN	Signal
VDD5_LVDS	2	1	VDD3_LVDS
VDD5_LVDS	4	3	VDD3_LVDS
EDP_DDC_SDA	6	5	EDP_DDC_SCL
GND	8	7	GND
DATA0_P	10	9	DATA1_P
DATA0_N	12	11	DATA1_N
GND	14	13	GND
DATA2_P	16	15	DATA3_P
DATA2_N	18	17	DATA3_N
GND	20	19	GND
DATA4_P	22	21	DATA5_P
DATA4_N	24	23	DATA5_N
GND	26	25	GND
DATA6_P	28	27	DATA7_P
DATA6_N	30	29	DATA7_N
GND	32	31	GND
LVDS_CLK1_P	34	33	LVDS_CLK2_P
LVDS_CLK1_N	36	35	LVDS_CLK2_N
GND	38	37	GND
VDD12_LVDS	40	39	VDD12_LVDS



# ECM-CDV Quick Installation Guide

## 2.3.13 USB connector 0&1 / 2&3 / 4&5 (USB2/ 3/ 4)



Signal	PIN	PIN	Signa
+5V	10	9	GND
USB_NP1/3/5	8	7	GND
USB_PP1/3/5	6	5	USB_PP0/2/4
GND	4	3	USB_NP0/2/4
GND	2	1	+5V

## 2.3.14 LPC connector (LPC1)





Signal	PIN	PIN	Signal
AD0	1	2	+V3P3_S
AD1	3	4	PLTRST#
AD2	5	6	LPC_FRAME#
AD3	7	8	LPC1_PCI_CLK
SERIRQ	9	10	GND
+V5S	11	12	GND
+V5A	13	14	LPC_LDRQ0#





# ECM-CDV Quick Installation Guide

## 2.3.15 SPI connector (SPI1)



Signal	PIN	PIN	Signal
		7	SPI_HOLD#
SPI_SI	6	5	SPI_SO
SPI_CLK	4	3	SPI_CS#
GND	2	1	+V3P3A_SPI



## 2.3.16 Serial port 2 connector (COM2)



Signal	PIN	PIN	Signal
DCDB#	1	2	RxDB
TxDB	3	4	DTRB#
GND	5	6	DSRB#
RTSB#	7	8	CTSB#
RIB#	9	10	NC



# ECM-CDV Quick Installation Guide

## 2.3.17 Keyboard & Mouse Connector (KB1)



Signal	PIN	PIN	Signal
KBDA	1	2	KBCK
GND_PS2	3	4	VCC_PS2
MSDA	5	6	MSCK
NC	7		



## 2.3.18 Serial port 2 in RS-422-485 mode (RS1)



Signal	PIN	PIN	Signal
485_422TX-	1	2	422RX-
485_422TX+	3	4	422RX+
+5V	5	6	GND



# ECM-CDV Quick Installation Guide

## 2.3.19 General purpose I/O connector (DIO1)



Signal	PIN	PIN	Signal
DI0	1	2	DO0
DI1	3	4	DO1
DI2	5	6	DO2
DI3	7	8	DO3
DI4	9	10	DO4
DI5	11	12	DO5
DI6	13	14	DO6
DI7	15	16	DO7
SMB_CLK	17	18	SMB_DATA
GND	19	20	+5V



## 2.3.20 SATA power connector (SPWR1)



Signal	PIN
GND	1
+5V	2



# ECM-CDV Quick Installation Guide

## 2.3.21 CPU fan connector (FAN1)



Signal	PIN
CPU_FANOUT	4
CPU_FANIN	3
+12V	2
GND	1

## 2.3.22 System fan connector (FAN2)



Signal	PIN
SYS_FANIN	3
+12V	2
GND	1

